



ACCUSTOR



HARDWARE DETAILED USER'S MANUAL v1.0

Copyright ©2015

This guide and any accompanying software and firmware are copyrighted. No parts of this publication may be reproduced, stored on a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopy, recording, or otherwise, without prior written consent except for copies retained by the purchaser for backup purposes.

All rights Reserved- Printed in Taiwan.

Notice

We make no warranties with respect to this documentation either express or implied and provide it "as it". This includes but is not limited to any implied warranties of merchantability and fitness for a particular purpose. The information in this document is subject to change without notice. We assume no responsibility for any errors that may appear in this document.

The manufacturer shall not be liable for any damage, or for the loss of information resulting from the performance or use of the information contained herein

Trademarks

Product names used herein are for identification purposes only and may be the trademarks of their respective companies. All trademarks or registered trademarks are properties of their respective owners.

Regulatory information



This drive is in conformity with the EMC directive.

Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules.

Those limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antennas.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning:

A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.

Use only shielded cables to connect I/O devices to this equipment.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

About This Installation Guide

Welcome to Hardware Installation Guide. This guide is designed to be used as step-by-step instructions for installation of your subsystem, and covers everything you need to know in learning how to operation, troubleshooting and future upgrades. For the detail about how to configure your subsystem, please refer to the Software Operation manual.

Symbols in Text

These symbols may be found in the text of this guide. They have the following meanings.



Caution

Caution

This icons indicates that failure to follow directions could result in personal injury, damage to your equipment or loss of information.



NOTE

Note

This icon presents commentary, sidelights, or interesting points of information.

Important terms, commands and programs are put in **Boldface** font.

Screen text is given in `screen` font.

Contents

About This Installation Guide	iv
Symbols in Text.....	iv
Contents.....	v
Chapter 1. INTRODUCTION.....	1
Model Variations	1
Features	1
Understanding the AccuSTOR RAID subsystem.....	3
<i>Front Panel Overview</i>	3
<i>Rear Panel Overview</i>	8
Chapter 2. INSTALLATION	12
Unpacking & checking the Equipment.....	12
What else you need.....	14
ESD Precaution	14
Installing hard disks.....	14
Install The AccuSTOR JBOD subsystem in a Rack.....	16
System Connection	18
Connection to the RAID System (Basic).....	19
Connection to the RAID System with more	19
SAS JBODs.....	19
Turning on for the first time	20
Turning off	21
Chapter 3. TROUBLE SHOOTING.....	22
Replace the Expander box	22

Hot Swapping to replace the Fan Module	23
Hot Swapping to replace the Power Module	25
Appendix A. Connectors.....	26
Appendix B. Firmware Updating	28
Appendix C.	30
Command Line Interface (CLI).....	30
Create a CLI connection.....	30
<i>Locations of RS-232C Port</i>	<i>30</i>
<i>Establishing the Connection for the Console(Terminal/RS-232)</i> <i>Port.....</i>	<i>30</i>
CLI Command Set	37
<i>HELP Command.....</i>	<i>37</i>
<i>PASS Command.....</i>	<i>38</i>
<i>LO Command.....</i>	<i>38</i>
<i>LINK Command.....</i>	<i>39</i>
<i>DHPM Command (Same as "EDFB")</i>	<i>42</i>
<i>TH Command.....</i>	<i>45</i>
<i>GROUP Command</i>	<i>48</i>
<i>SYS Command.....</i>	<i>50</i>
<i>BU Command.....</i>	<i>51</i>
<i>FAN Command</i>	<i>52</i>
<i>SPIN Command.....</i>	<i>54</i>

<i>ST Command</i>	55
<i>LSD Command</i>	56
<i>SHOWLOGS Command</i>	58
<i>FDL Command</i>	59
<i>Counters Reset Command</i>	61
<i>Sasaddr Command</i>	62
Appendix D.	63
LCD Configuration Manager	63
Appendix E. Specifications	67
Specifications	67

Chapter 1. INTRODUCTION

This chapter introduces the features and capabilities of AccuSTOR 12Gb SAS to 12Gb SAS JBOD subsystems.

You will find:

- ⇒ A full introduction to your JBOD SYSTEM
- ⇒ Details of key features and supplied accessories
- ⇒ A checklist of package contents
- ⇒ A checklist of what else you need to start installation

Model Variations

There are Four available models in AccuSTOR 12Gb JBOD subsystem series; which utilize Single 12Gbps miniSAS HD connector as Host interface and dual 12Gbps miniSAS HD connectors for expansion, each with 12, 16, or 24 device bays.

<i>Model Name</i>	<i>Host Interface</i>	<i>Device bays</i>	<i>Controller Numbers</i>
AS424X12(R)	SAS (miniSAS HD)	24 bays	1 or 2
AS316X12(R)	SAS (miniSAS HD)	16 bays	1 or 2
AS212X12(R)	SAS (miniSAS HD)	12 bays	1 or 2
AS224X12(R)	SAS (miniSAS HD)	24 bays	1 or 2

Features

The 12Gb JBOD system is designed to meet today's large volume and excellent performance storage requirements in rapidly changing business environment. It provides a maximum data protection and exceptional performance in a storage subsystem. Target usage ranges are set from small business to departmental and corporate server needs. The 12Gb JBOD system is designed for easy integration, smooth data expansion and server migration.

The firmware of 12Gb JBOD system has been included the failover to utilize the most up-to-date technology available, providing your system with reliable, high-quality performance. User can configure redundant mode with two expander module using either RAID controllers or HBAs to achieve failover protection. Each expander board features three 12Gb/s Mini SAS HD (SFF-8644) connectors; default setting one for host and two for expansion to additional JBOD enclosures.

For host and easy expansion. High Performance Architecture sets new boundaries of industry performance expectations! 12Gb/s SAS (1200MB/s bandwidth per physical link) 12Gb/s SAS/SATA (1200MB/s bandwidth per physical link). The DataBolt™ Bandwidth Optimizer is designed to help facilitate the industry transition to 12Gb/s SAS-enabled systems by allowing users to take advantage of 12Gb/s speeds while utilizing existing 12Gb/s drives and backplanes. The expander buffers 12Gb/s data and then transfers it out to the host at 12Gb/s speeds in order to match the bandwidth between faster hosts and slower SAS or SATA devices.

The 12Gb JBOD systems contains an embedded expander manager that can access via in-band SES-2 over SMP protocol and out-of band RS-232 port. An out-of-band serial port is available for managing the configuration and monitoring the expander.


The 12 Gb JBOD system supports the following features:

- Supports 12Gb/s SAS and 6Gb/s SATA disk drives.
- Single (4x wide-port) minSAS HD connector for host connection.
- Dual (4x wide-port) minSAS HD connectors for expander module daisy chain.
- Redundant and Hot Swappable JBOD expander I/O board, Fan, Power and Drives.
- Completely monitored by In-band SES (SAS Port), out-of-band RS232 serial port.
- CLI through RS232 serial port
- Supports “DataBolt™ Bandwidth Optimizer” to take the advantage of 12Gb/s speed with slower SAS and SATA devices.
- Configuration and environmental information is accessible either via the Serial Port or RAID System.
- Load sharing, hot swappable redundant power system with PFC function.

Understanding the AccuSTOR RAID subsystem

Front Panel Overview

LCD Module



Function keys. (ENT, ESC, Scroll up, Scroll Down)

Keys	Descriptions
Up Arrow	To scroll upward through the menu items
Down Arrow	To scroll downward through the menu items
(ENT) Enter	To confirm a selected item
(ESC) ESC	To exit a sub-menu and return to previous menu.


There are three LED indicators on the front panel. Following table provides a summary of the meanings of these LED indicators:

LED Indicator	Normal Status	Problem Indication
Power On indicator	Bright Blue	This LED does not light up after power switched on
Fail Indicator	LED never light up	LED light up as Red.
Data Access Indicator	Blink blue during host computer accessing the RAID subsystem.	LED never flickers


Driver Bay numbering convention

The enclosure bay numbering convention is shown in following figure. A bay is designed to house a single 3.5-inch hard disk drive or a 2.5" hard disk in his carrier module.


AS424X12(R)




AS316X12(R)




AS212X12(R)




AS224X12(R)




Drive Bay for 3.5" Series




Drive Bay for 2.5" Series






Rear Panel Overview

AS424X12(R)



AS316X12(R)



1. Expander Box 1.
2. Expander Box 2
3. SAS CH 0 & LED Indicator

LED	Colors	Indicate
-----	--------	----------

SAS	Green	Link
	Blue + Blink	Access

4. SAS Expand Port 1 & LED Indicator

LED	Colors	Indicate
SAS	Green	Link
	Blue + Blink	Access


5. SAS Expand Port 0 & LED Indicator

LED	Colors	Indicate
SAS	Green	Link
	Blue + Blink	Access

6. Console (Terminal Port)
7. Reserved
8. Power Switch
9. FAN failure indicator (Rear / Front)
10. FAN Module 1
11. FAN Module 1 latch
12. FAN failure indicator (Rear / Front)
13. FAN Module 2
14. FAN Module 2 latch
15. AC inlet 1 & Latch
16. Power Module 1
17. AC inlet 2 & Latch
18. Power Module 2

AS212X12(R)

AS224X12(R)



1. Expander Box 1.
2. Expander Box 2
3. SAS CH 0 & LED Indicator

LED	Colors	Indicate
SAS	Green	Link
	Blue + Blink	Access

4. SAS Expand Port 1 & LED Indicator

LED	Colors	Indicate
SAS	Green	Link
	Blue + Blink	Access

5. SAS Expand Port 0 & LED Indicator

LED	Colors	Indicate
SAS	Green	Link
	Blue + Blink	Access

6. Console (Terminal Port)
7. Reserved
8. Power Switch

9. FAN failure indicator 1.(Rear / Front)
10. FAN Module 1
11. FAN failure indicator 2 (Rear / Front)
12. FAN Module 2
13. AC inlet 1 & Latch
14. Power Module 1
15. AC inlet 2 & Latch
16. Power Module 2

Chapter 2. INSTALLATION

This chapter presents:

- ⇒ Instructions on unpacking & checking the equipment
- ⇒ Instructions on how to install Hard disk drive
- ⇒ Instructions on how to install AccuSTOR JBOD in a Rack.
- ⇒ Instructions on how to connect AccuSTOR JBOD.

Unpacking & checking the Equipment

Before unpacking the AccuSTOR JBOD subsystem, prepare a clean, stable surface to put on the contents of AccuSTOR JBOD shipping container. Altogether, you should find following items in the package:

AccuSTOR Series 12Gb SAS to SAS/SATA JBOD Subsystem:

- JBOD subsystem x1
- CD-ROM x 1 (Includes Hardware Installation Guide).
- Serial cable x1
- Power Cord x 2 (AS316X12(R) and AS212X12(R)), Power Cord x 3 (AS424X12(R))
- miniSAS HD cable (SFF-8644) x 1
- Drive Bay, (AS212X12(R) x 12, AS316X12(R) x 16, AS424X12(R) x 24)
- Key for Drive Bay x 4
- Slide Kit (Rails) for Rack
- Mounting screws : for 3.5" disks (bag) x 1 / for 2.5" disks (bag) x 1

AccuSTOR 2.5" Series 12Gb SAS to SAS/SATA JBOD Subsystem:

- JBOD subsystem x1
- CD-ROM x 1 (Includes Hardware Installation Guide).
- Serial cable x1

- Power Cord x 2 (AS224X12(R))
- miniSAS HD cable (SFF-8644) x 1
- Drive Bay x 24
- Key for Drive Bay x 4
- Slide Kit (Rails) for Rack
- Mounting screws : for 2.5" disks (bag) × 1

What else you need

- Hard disk drives (different RAID levels requires different numbers of HDDs. Refer to Software Operation manual for more detail information.
- Host computer with SAS interface or AccuSTOR RAID subsystem.
- Dedicated terminal or PC with third party communication software that supports ANSI terminal emulation (required for viewing Monitor Utility)

ESD Precaution


Use a suitable anti-static wrist or ankle strap and observe all conventional ESD precaution when handle AccuSTOR JBOD's modules and components. Avoid contact with backplane components and module connectors.

Installing hard disks

The AccuSTOR JBOD series includes 12, 16, 24 hot swappable drive bays. The following sections describe how to install disks into AccuSTOR JBOD subsystems.


Loading 2.5" Hard Disk to the drive bay. (for AccuSTOR Series)

1. Put 2.5 HDD into the bay.
2. Fasten all 4 screws to mount HDD in the bay and make sure the HDD is properly tightened.




Loading 3.5" Hard Disk to the drive bay. (for AccuSTOR Series)

1. Put 3.5 HDD into the bay.
2. Fasten all 4 screws to mount HDD in the bay and make sure the HDD is properly tightened.



Loading 2.5" Hard Disk to the drive bay. (for AccuSTOR 2.5" Series)

1. Put 2.5 HDD into the bay.
2. Fasten all 4 screws to mount HDD in the bay and make sure the HDD is properly tightened.



Place drive bays back into the system

1. Slide in drive bay; make sure the handle is open fully.
2. Close the handle to engage the drive bay into the slot.



NOTE

Note

The hard drives in a JBOD should match in size and speed. All drives in any array should be identical models with the same firmware versions.



Caution

Caution

Only use the screws offered with AccuSTOR RAID subsystem. Longer screws might cause the drive damage.

All the drive bays (with or without hard drive) must be placed in the AccuSTOR subsystem. AccuSTOR's cooling system is designed with full of drive bays. Missing drive bays might cause the subsystem damage.

Install The AccuSTOR JBOD subsystem in a Rack

You are shipped one rackmounting kit for each AccuSTOR subsystem that you intend to rackmount. AccuSTOR subsystem is designed for installation into a industry-standard 19-inch rackmount cabinet. Following the use of this section for installing the AccuSTOR subsystem into a Rack

Install the Slide Rails

1. Combine Left slide rail and rear slide rail.
2. Measure the depth of the rack enclosure, then fasten 4 of P4*8M screws into M4 Locking nuts to fix the length.
3. Use T5*8M screws and PW14 washer to install the left slide on Front and rear Posts of Rack as Figure 1.
4. Repeat procedure 1 ~ 3 to install the right Slide into the Rack.




Figure 1.

Place the AccuSTOR Subsystem into the rack

1. Lift the subsystem enclosure and slide it slowly and gently along the slide rail into the rack as Figure 2.




Figure 2.

2. Fasten two M5 screws through the chassis ears in the front side of the chassis to secure the AccuSTOR subsystem in the rack as Figure 3.




Figure 3.



Caution

Caution

The AccuSTOR subsystem is heavy, two person are required to move the system in the procedure.

System Connection

Connect all cables and power cord as shown below:

Cable	AccuSTOR JBOD	Device	Purpose
Serial Cable	Console	ANSI Terminal or PC with Terminal emulator.	Configuration Utility
MiniSAS HD Cable	SAS CH0	SAS HBA of Host computer AccuSTOR SAS RAID subsystem	Host interface between JBOD and Host computer
Power Cord	Power inlet	A/C power outlet	A/C power input
MiniSAS HD Cable	SAS Exp.	AccuSTOR JBOD	Connect to SAS Expander




NOTE


Note

Make sure that all the devices are powered off before connecting or removing cables to prevent power spikes which can damage technical components.

Connection to the RAID System (Basic)



Connection to the RAID System with more SAS JBODs



It supports up to four tiers and 256 drives.

- One RAID Set supports up to 32 HDDs
- One SAS RAID subsystem supports up to 128 Volumes
- One SAS RAID subsystem supports up to 256 SAS devices

There are four tiers within JBOD topology as above:

- First tier is a RAID System.
- Second tier is a SAS JBOD with a SAS CH0 on it. Connecting SAS CH0 to SAS exp. Port on RAID System via a MiniSAS HD Cable.
- Third tier could be two SAS JBODs with a SAS CH0 port individually. One is connected to the SAS EXP. Port on the second tier SAS JBOD via a MiniSAS HD Cable. Another is connected to the SAS CH1/E Port on the second tier SAS JBOD
- Fourth tier is a SAS JBOD with a SAS CH0 on it. Connecting SAS CH0 to SAS exp. Port on third tier SAS JBOD via a MiniSAS HD Cable.



NOTE

1. *AccuSTOR Gen2 subsystem do not require the installation of different drivers for use with different operating systems. AccuSTOR Gen2 system is independent and transparent to the host operating system.*
 2. *It is often recommended to install the hard drive with same brand, model no., interface and capacity in this RAID subsystem.*
 3. *Please do not install SAS and SATA hard drives at the same time, as these hard drives spin at different speed and may lead to compatible issues or performance decline.*
 4. *RAID members need to be included at the same enclosure that means you need to create array in the same enclosure. RAID members across two or more enclosures would get some risks (for example: if mini-SAS cable get problem, more RAID members will be lost, volume sets belong to this Array may be failed. Shutdown RAID and JBOD to fix problem, after that, turn on JBOD and RAID system again and controller will get array back, but in some special case maybe it can't get array back)*
-

Turning on for the first time

When cabling is completed, RAID system + 12Gb/s SAS JBOD system can be turned on. This should be done in the following order:

1. First turn on the power switch of 12Gb/s JBOD system.
2. Then turn on the power switch of RAID system
3. Power on and boot the host computer(s)

Turning off

When turning off RAID system + 12Gb/s JBOD system, users are advised to first shut down the server, then power off RAID SYSTEM ,finally power off 12Gb/s JBOD SYSTEM.

Chapter 3. TROUBLE SHOOTING

This chapter contains trouble shooting procedures and suggestions to minimize their impact on the AccuSTOR JBOD operation :

⇒ Instructions on how to replace the components of AccuSTOR JBOD subsystem.

If the fault LED on the front panel of AccuSTOR JBOD lights, or if AccuSTOR RAID's Internet manager indicates a fault of JBOD, determine the reason for this alert immediately. Examine the component LEDs to see if any indicates a fault, then replace it as soon as possible.

Replace the Expander box




Caution

Read the replacing notices earlier in this chapter before proceeding with replacement.

This section provides instructions for the removal and installation of the Expander box components indicated in the figure below. This section is for the reference of engineers. End users should not need to replace or remove components.

Removing the JBOD Expander box from AS316X12(R) and AS424X12(R) JBOD :


In order to access expander box, turn anti-clock wise to release two thumb screws, then use the eject bar to remove Controller box.



Removing the JBOD Expender box from AS212X12(R) & AS224X12(R) JBOD :

In order to access controller box,

1. Turn anti-clock wise to release the thumb Screws.
2. Push down the use eject bar to remove Controller box.



Installing the Expander box into JBOD subsystem:


Reverse the procedure of “**removing the controller**” to install the controller into AccuSTOR JBOD Subsystem.

Hot Swapping to replace the Fan Module

This section provides instructions for the removal and installation of the Fan Module indicated in the figure below.


Removing the Fan Module from AS316X12(R) and AS424X12(R) :

Remove the Fan modules by slide the release button left and pull the module out of system.




Replace the Fan in Fan module

1. There are two failure LEDs on the rear of Fan module. Check which LED lights to yellow.
2. Remove the Fan modules by anti-clock wise to release the thumb screw then slide it back and lifting off.
3. Release the screw to remove the defect fan.
4. Insert the spare Fan and fasten the screw.



Removing the Fan Module from AS212X12(R) & AS224X12(R) JBOD :

Remove the Fan modules by slide the release button left and pull the module out of system,




Hot Swapping to replace the Power Module

This section provides instructions for the removal and installation of the Power Module indicated in the figure below.

Removing the Power Module

Unscrew the thumb fastener, then push right the release button, slide it back and lifting off.



Installing the Power module into AccuSTOR:

Insert a Power module then fasten the screw.




NOTE

The Power indicator will turn bright "Green" to indicate it has powered on


Appendix A. Connectors

RJ-11



Pin#	Signal	Pin#	Signal
1	NC	6	NC
2	GND		
3	RX		
4	TX		
5	CTS		

miniSAS HD (SFF-8644)




Signal	Pin Number#
Rx 0+	B4
Rx 0	B5
Rx 1+	A4
Rx 1	A5
Sideband 7	A1
Sideband 3	B1
Sideband 4	C1
Sideband 5	D1
Rx 2+	B7
Rx 2	B8
Rx 3+	A7
Rx 3	A8
Tx 0+	D4
Tx 0	D5
Tx 1+	C4
Tx 1	C5
Sideband 0	A2
Sideband 1	B2
Sideband 2	C2
Sideband 6	D2
Tx 2+	D7
Tx 2	D8
Tx 3+	C7
Tx 3	C8
SIGNAL GROUND	A3, A6, A9, B3, B6, B9, C3, C6, C9, D3, D6, D9


Appendix B. Firmware Updating

The procedure to update firmware of JBOD shall thru the UART, please refer to “**Appendix C. Command Line Interface**” to create a CLI connection, then follow the steps as bellowing to update the firmware of JBOD.

1. First type "fdl code" under "CLI>" prompt,



2. Then under hyper terminal click “file” at top to pull down the menu. Choose "Xmodem" and select the firmware file in the directory then press send to attach file. If file is receiving within the timeout limit (60sec), then firmware update will proceed. If a timeout message appear, please retry the step 2 again.



The firmware date are presented in the following filename format,

- a. FW file(code):sas2xfwXXXX.fw
- b. Data file(mfgb): mfgdat6gYYYY.rom

3. Firmware update procedure can be stopped by pressing Q or q.
6. Perform a cold-start after the firmware updating is completed.
7. After the firmware updating is completed, repeat steps 1-6 to update the Data file, but change the CLI command as following.

CLI> fdl mfgb

Then use file "mfgdata.rom" to update the Datafile.

8. After both files are updated, restart the expander.
9. After restart the expander, repeat steps 1-6 to update the Code file again.
10. After both files are updated, restart the expander.

Appendix C.


Command Line Interface (CLI)

This Command Line Interface (CLI) is provided for you to manage the 12Gb JBOD system series 12/16/24 system functions. The CLI is useful in environments where a graphical user interface (GUI) is not available.

Create a CLI connection

Locations of RS-232C Port

The 12Gb JBOD system uses the RJ11 port as the serial port interface. Please use the cable included in the shipping box to configure the expander controller.



Console (Terminal Port)

Establishing the Connection for the Console(Terminal/RS-232) Port

The CLI function can be done by using an ANSI/VT-100 compatible terminal emulation program. You must complete the appropriate installation procedure before proceeding with the CLI function. Whichever terminal emulation program is used must support the 1K XMODEM file transfer protocol.

The Console (Terminal/RS-232) port on the JBOD system I/O shield can be used in VT100 mode. The provided interface cable converts the RS232 signal of the RJ11 connector on the JBOD system into a 9-pin D-Sub male connector. The firmware-based terminal SAS expander management interface can access the expander through this Terminal/RS-232 port. You can attach a VT-100 compatible terminal or a PC running a VT-100 terminal emulation program to the serial port for accessing the text-based setup menu.

To ensure proper communications between them JBOD subsystem and the VT-100 Terminal Emulation, please configure the VT100 terminal emulation settings to the values shown below:

Terminal requirement	
Connection	Null-modem cable
Baud Rate	115,200
Data bits	8
Stop	1
Flow Control	None

The JBOD Subsystem's RJ-11 connector's pin assignments are defined as below:


RS-232C Pin Assignments			
Pin	Description	Pin	Description
1	N/C	6	NC
2	GND		
3	RX		
4	TX		
5	CTS		

By connecting a VT100 compatible terminal, or a PC operating in an equivalent terminal emulation mode, all RAID subsystem monitoring, configuration and administration functions can be exercised from the VT100 terminal.


There are a wide variety of Terminal Emulation packages, but for the most part they should be very similar. The following setup procedure is an example Setup of VT100 Terminal in Windows XP system using Hyper Terminal Version 5.1.


Step 1. From the Desktop open the Start menu. Pick All Programs, Accessories, Communications and Hyper Terminal. Open Hyper Terminal (requires version 3.0 or higher)

Installation Guide




Step 2. Open HYPERTRM.EXE.






Step 3. Enter a name for your Terminal. Click OK.




Step 4. Select an appropriate connecting port in your Terminal. Click OK


Installation Guide




Step 5. Configure the port parameter settings. Bits per second: "115200", Data bits: "8", Parity: "None", Stop bits: "1", Flow control: "None". Click OK



Step 6. Open the File menu, and then open Properties.




Step 7. Open the Settings Tab.



Installation Guide

Step 8. Open the Settings Tab. Function, arrow and ctrl keys act as: Terminal Keys, Backspace key sends: Ctrl+H, Emulation: VT100, Telnet terminal: VT100, Back scroll buffer lines: 500. Click OK.



Now, the VT100 is ready to use.

CLI Command Set

This section provides detail information about the 12Gb JBOD Subsystem's CLI function. All the commands please type in lower case.

The CLI has the following commands:

HELP Command

This command provides an on-line table of contents, providing brief descriptions of the help sub-commands. You can use the <CLI> help to get detail information about the CLI commands summary.

Syntax

```
CLI>help[Enter]
```

Example:

```
CLI>help
```

Pass	- Set Password
Lo	- Logout CLI Shell
Link	- Link Rate Control
dhpm(edfb)	- Bandwidth Optimizer
th	- Temperature Control
group	- Set the PHY Group
sys	- System Information
bu	- Alarm Control
fan	- Fan Speed Control
spin	- Drive SpinUp Control
st	- Store System Setting
lsd	- List Devices Status
showlogs	- Show the Current Logs
fld	- File Download
counters reset (optional)	- Display/Reset all phy counters

sasaddr - Display expander SAS
address

PASS Command

The pass command allows user to set or clear the SAS JBOD password protection feature. Once the password has been set, the user can only monitor and access the SAS JBOD setting by providing the correct password. The password can accept max 8 chars and min. 4 chars. The manufacture default password is “0000”.

Syntax

```
CLI>pass [Enter]
```

Example:

```
CLI>pass
```

```
Old Password:****
```

```
New Password:****
```

```
Verify New Password:****
```

Password Changed But Not Save Permanently!

Note, use CLI command “st” to keep permanently.

LO Command

To exit the selected SAS JBOD CLI shell, use the lo command.

Syntax

```
CLI> lo [Enter]
```

Example:

```
CLI>lo
```

```
Password:
```

LINK Command

The link command allows you to set the operate device link rate that has been connected on expander controllers. Typical parameters include: Max and Min disk speed connected the SAS JBOD and High and Low external cable link speed connected the SAS JBOD.

1. Set external cable link speed rate

Syntax

```
CLI>link c[0|1|2|3] High Low]
```

Index: c[0|1|2|3] External Cable Index

The cable c0, c1, or c2 is view from right to left or start from top to bottom.

High-Rate, Low-Rate: [11(12G)|10(6G)|9(3G)]

PS. Pls. Save Config. & Reboot To Take Effect

```
CLI>st
```

Example:

```
CLI>link c0,c1 10 9 ;; set cable0 and cable1 link speed range [max=10(6G),
min=9(3G)]
```

```
CLI>st
```

```
CLI>
```

Reboot to take effect.

2. Set all slots with same link speed rate

Syntax

```
CLI>link [Index(D)| 255] High-Rate(D) Low-Rate(D)
```

Index: Slot Index

High-Rate, Low-Rate: [11(12G)|10(6G)|9(3G)]

6.0G, and 11 means 12.0G

PS. Pls. Save Config. & Reboot To Take Effect

CLI>st

Example:

CLI>link 255 10 9 ;; set all slots with same link speed rate, max=10(6G),
min=9(3G)

CLI>st

CLI>

Reboot to take effect.

3. Set internal slot link speed rate

Syntax

CLI>link [Index Max Min] [Enter]

Index: Slot Index

High-Rate, Low-Rate: [11(12G)|10(6G)|9(3G)]

PS. Pls. Save Config. & Reboot To Take Effect

CLI>st

Example:

CLI>link

ArrayDevice Element (0x17):

```
=====
```

NAME	PHY	ORG	NLR	MAX	MIN	TYPE	ADDRESS
SLOT 01		13	6G	6G	11	9	SATA 5001B469-189AE00D
SLOT 02		12	6G	6G	11	9	SAS 5011B469-189AE00C
SLOT 03		14	6G	6G	11	9	SATA 5011B469-189AE00E
SLOT 04		15	6G	6G	11	9	SATA 5011B469-189AE00F


```

SLOT 05      9      6G      6G      11      9      SATA  5011B469-
189AE009
SLOT 06      8      6G      6G      11      9      SATA  5011B469-
189AE008
SLOT 07     10      6G      6G      11      9      SATA  5011B469-
189AE00A
SLOT 08     11      6G      6G      11      9      SATA  5011B469-
189AE00B
SLOT 09      5      6G      6G      11      9      SATA  5011B469-
189AE005
SLOT 10      4      6G      6G      11      9      SATA  5011B469-
189AE004
SLOT 11      6      3G      3G      11      9      SAS
                    500000E0-168F8E92
SLOT 12      7      3G      3G      11      9      SAS
                    500000E0-168F8E99

```

//Set the slot 0x6 max. speed to 3.0G

CLI >link 6 9 9

CLI>st

CLI>

Reboot to take effect.

CLI >link

ArrayDevice Element (0x17):

=====

NAME	PHY	ORG	NLR	MAX	MIN	TYPE	ADDRESS
SLOT 01		13	6G	6G	11	9	SATA 5001B469-189AE00D
SLOT 02		12	6G	6G	11	9	SAS 5011B469-189AE00C

SLOT 03	14	6G	6G	11	9	SATA	5011B469-189AE00E
SLOT 04	15	6G	6G	11	9	SATA	5011B469-189AE00F
SLOT 05	9	6G	6G	11	9	SATA	5011B469-189AE009
SLOT 06	8	6G	3G	9	9	SATA	5011B469-189AE008
SLOT 07	10	6G	6G	11	9	SATA	5011B469-189AE00A
SLOT 08	11	6G	6G	11	9	SATA	5011B469-189AE00B
SLOT 09	5	6G	6G	11	9	SATA	5011B469-189AE005
SLOT 10	4	6G	6G	11	9	SATA	5011B469-189AE004
SLOT 11	6	3G	3G	11	9	SAS	500000E0-168F8E92
SLOT 12	7	3G	3G	11	9	SAS	500000E0-168F8E99

DHPM Command (Same as "EDFB")

Use for 3G/6G SAS/SATA drive speed up as 12G drive performance. DataBolt™ Bandwidth Optimizer is designed to help facilitate the industry transition to 12Gb/s SAS-enabled systems by allowing users to take advantage of 12Gb/s speeds while utilizing existing 6Gb/s drives or backplanes.

Syntax

```
CLI> dhpm [on | off] [i,j,..] [Enter]
```

on - turn on all drive slot as 12G performance mode.

off - turn off all drive slot 12G performance mode.

i,j,.. - turn on/off drive slot i,j, ...12G performance mode.

Example:

CLI>help dhpm

Drive High Performance dhpm { [on | off] [i,j,..] }

CLI>link

ArrayDevice Element (0x17):

```
=====
```

NAME	PHY	ORG	NLR	MAX	MIN	TYPE	ADDRESS
SLOT 01		13	6G	6G	11	9	SATA 5001B469-189AE00D
SLOT 02		12	6G	6G	11	9	SAS 5011B469-189AE00C
SLOT 03		14	6G	6G	11	9	SATA 5011B469-189AE00E
SLOT 04		15	6G	6G	11	9	SATA 5011B469-189AE00F
SLOT 05		9	6G	6G	11	9	SATA 5011B469-189AE009
SLOT 06		8	6G	6G	11	9	SATA 5011B469-189AE008
SLOT 07		10	6G	6G	11	9	SATA 5011B469-189AE00A
SLOT 08		11	6G	6G	11	9	SATA 5011B469-189AE00B
SLOT 09		5	6G	6G	11	9	SATA 5011B469-189AE005

Installation Guide

SLOT 10	4	6G	6G	11	9	SATA	5011B469-189AE004
SLOT 11	6	3G	3G	11	9	SAS	500000E0-168F8E92
SLOT 12	7	3G	3G	11	9	SAS	500000E0-168F8E99

CLI>dhpm on 2,12 ;;;; set drive slot 2,12 on

CLI>st

Reset or PowerCycle

CLI>link

ArrayDevice Element (0x17):

```
=====
```

NAME	PHY	ORG	NLR	MAX	MIN	TYPE	ADDRESS
SLOT 01		13	6G	6G	11	9	SATA 5001B469-189AE00D
SLOT 02		12	6G	12G	11	9	SAS 5011B469-189AE00C
SLOT 03		14	6G	6G	11	9	SATA 5011B469-189AE00E
SLOT 04		15	6G	6G	11	9	SATA 5011B469-189AE00F
SLOT 05		9	6G	6G	11	9	SATA 5011B469-189AE009
SLOT 06		8	6G	6G	11	9	SATA 5011B469-189AE008
SLOT 07		10	6G	6G	11	9	SATA 5011B469-189AE00A
SLOT 08		11	6G	6G	11	9	SATA 5011B469-189AE00B

```

SLOT 09      5      6G      6G      11      9      SATA  5011B469-
189AE005
SLOT 10      4      6G      6G      11      9      SATA  5011B469-
189AE004
SLOT 11      6      3G      3G      11      9      SAS
500000E0-168F8E92
SLOT 12      7      3G      12G    11      9      SAS
500000E0-168F8E99

```

CLI>dhpm on ;;;; set all drives on

CLI>st

Reset or PowerCycle

TH Command

The th command allows you to set the operate device temperature warning limit. Typical parameters include: High-Warn and Low-Warn are warning temperature in Celsius.

Syntax

CLI> th Index High-Warn Low-Warn

Example:

CLI>th

Temperature Element (0x04):

```

=====
NAME              ID    CT('C) HTW          LTW    OTWarn
ENC.Temp          01    30          60          5
    No
Chip Temp         02    64          90          5
    No

```

Installation Guide

Slot01 Temp	03	31	60	5
No				
Slot02 Temp	04	32	60	5
No				
Slot03 Temp	05	30	60	5
No				
Slot04 Temp	06	31	60	5
No				
Slot05 Temp	07	36	60	5
No				
Slot06 Temp	08	32	60	5
No				
Slot07 Temp	09	32	60	5
No				
Slot08 Temp	10	35	60	5
No				
Slot09 Temp	11	34	60	5
No				
Slot10 Temp	12	32	60	5
No				
Slot11 Temp	13	32	60	5
No				
Slot12 Temp	14	32	60	5
No				

CLI>th 2 79 0

Temperature Element (0x04):

=====

NAME	ID	CT('C)	HTW	LTW	OTWarn	
ENC. Temp	01	30		60	5	No

Chip Temp	02	64	79	0	No
Slot01 Temp	03	31	60	5	No
Slot02 Temp	04	32	60	5	No
Slot03 Temp	05	30	60	5	No
Slot04 Temp	06	31	60	5	No
Slot05 Temp	07	36	60	5	No
Slot06 Temp	08	32	60	5	No
Slot07 Temp	09	32	60	5	No
Slot08 Temp	10	35	60	5	No
Slot09 Temp	11	34	60	5	No
Slot10 Temp	12	32	60	5	No
Slot11 Temp	13	32	60	5	No
Slot12 Temp	14	33	60	5	No

CLI>st

CLI>

Reboot to take effect.

CLI>th

Temperature Element (0x04):

=====

NAME	ID	CT('C)	HTW	LTW	OTWarn	
ENC. Temp	01	30		60	5	No
Chip Temp	02	64		79	0	No
Slot01 Temp	03	31		60	5	No
Slot02 Temp	04	32		60	5	No
Slot03 Temp	05	30		60	5	No
Slot04 Temp	06	31		60	5	No
Slot05 Temp	07	36		60	5	No
Slot06 Temp	08	32		60	5	No

Slot07 Temp	09	32	60	5	No
Slot08 Temp	10	35	60	5	No
Slot09 Temp	11	34	60	5	No
Slot10 Temp	12	32	60	5	No
Slot11 Temp	13	32	60	5	No
Slot12 Temp	14	33	60	5	No

GROUP Command

The group command is used to associate the external port with the devices/phys as one zone group. The three external cable ports and all devices/phys slots will default associate with one zone group.

Syntax

```
gr {dev GroupNo[1..] {ci, cj, ck,...} Start-Index(D) End-Index(D)}
```

```
gr {off | [t10 off] }
```

dev : use drive slot index

GroupNo : groupno start from 1, max 8 groups ci, cj, ck,...

external cable connector. i, j, k,.. is the index which range from 0 to 3. According to view from connector side, index start from right to left or top to bottom. The cable c0, c1, or c2 is view from right to left or start from top to bottom.

Start-Index : Start slot index of zone range, [1.. max drive]

End-Index : End slot index of zone range, [1.. max drive]

off : clear the zone group setting.

t10 off : turn T10 mode off.

Example:

```
CLI>gr
```

```
Current PHY Group Mode: T10
```

```
Group-1: C0, C1, C2, Slot: 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16
```

```
Value: 0x0000000FFFFFFFFF
```


//Set the cable0 and slot 1 to slot 6 as group 1

CLI>gr dev 1 c0 1 6

New PHY Group Mode: T10

Group-1: C0, Slot: 1, 2, 3, 4, 5, 6

Value: 0x000000000000FFC00

Current PHY Group Mode: T10

Group-1: C0, C1, C2 Slot: 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16

Value: 0x00000000FFFFFFFFF

//Set the cable1 and cable2 and slot 7 to slot 16 as group 2

CLI>gr dev 2 c1, c2 7 16

New PHY Group Mode: T10

Group-1: C0, Slot: 1, 2, 3, 4, 5, 6

Value: 0x000000000000FFC00

Group-2: C1, C2, Slot: 7, 8, 9, 10, 11, 12, 13, 14, 15, 16

Value: 0x0000000000FF003FF

Current PHY Group Mode: T10

Group-1: C0, C1, C2 Slot: 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16

Value: 0x00000000FFFFFFFFF

CLI>st

Power Cycle to reboot

CLI>gr

Current PHY Group Mode: T10

Group-1: C0, Slot: 1, 2, 3, 4, 5, 6

Value: 0x000000000000FFC00

Group-2: C1, C2, Slot: 7, 8, 9, 10, 11, 12, 13, 14, 15, 16

Value: 0x00000000FF003FF

//Clear the Zone group Setting

CLI>gr off

New PHY Group Mode: T10

Group-1: C0, C1, C2 Slot: 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16

Value: 0x000000FFFFFFFF

Current PHY Group Mode: T10

Group-1: C0, Slot: 1, 2, 3, 4, 5, 6

Value: 0x0000000000FFC00

Group-2: C1, C2, Slot: 7, 8, 9, 10, 11, 12, 13, 14, 15, 16

Value: 0x00000000FF003FF

SYS Command

The sys command is used to view the expander's information. Typical information includes: vendor, model name, serial/unit number, expander port number, product revision, chip name/chip revision, customer code, manufacture data revision and work time.

Syntax

CLI>sys [Enter]

Example:

CLI>sys

=====
Hardware Revision Information:-

=====
Vendor ID : AccuSTOR

Taiwan, R.O.C

Model ID : AN612

Serial No. : 0000000000000000

Unit Serial No. :

Expander SAS Address : 0x5001B469189AE03F

Product Revision : 0

Expander Chip ID : 0x0233 (Ports : 36)

Expander Chip Revision : C0

Customer Code : 0x35 (R01)

Manufacturer Data Revision : 0x01 12/12/13

Working Time : Day00000-00:00:06

Dual Mode : Single

=====

Firmware Revision Information:-

=====

Boot Image:

Revision: 100.BD.00.0A 12/05/13

Firmware Family: 0 OemFamily: 0

Fast Boot: Yes Image Address: 0x10000000

Firmware Copy 1:

Revision: 100.BD.01.0A 01/06/14

Firmware Family: 0 OemFamily: 0

Fast Boot: Yes Image Address: 0x10100000

Firmware Copy 2: [Active]

Revision: 100.BD.01.0A 01/06/14

Firmware Family: 0 OemFamily: 0

Fast Boot: Yes Image Address: 0x10200000

HAL Revision: 0.1.0.0 SES Revision: 0.1.0.0 SCE Revision:

0.1.0.0

BU Command

The BU command allows you to control the buzzer attributes that have been controlled by SAS expander H/W. There are four sound levels defined by the expander H/W. The default warning is sound level 2 and critical: sound level 3.

Syntax

```
CLI>BU [Warning Critical] [MUTE] [Enter]
```

Example:

```
CLI>BU
```

Buzzer Attribute:

Warning Beep: Sound 2

Critical Beep: Sound 3

```
CLI>BU 0x1 0x3
```

CLI>BU Buzzer Attribute:

Warning Beep: Sound 1

Critical Beep: Sound 3

```
CLI>
```

When expander alarm with buzzer, you can temporarily mute it with the following command. The buzzer still can be activated by the next different event.

```
CLI>BU MUTE
```

When expander alarm with buzzer, you can disable it completely by command “bu 0 0”. If you would like to enable beeper, the command for default settings will be “bu 2 3”.

FAN Command

The fan command allows you to set the operate fan speed. Typical parameters include: LowestSpeed and WarningSpeed are fan speed in speed code from level 1 to 7. The LowestSpeed is the speed code that fan operate in normal state, and the WarningSpeed is the speed code that fan operate in warning state; like as detect a device in over-temperature.

Syntax

```
CLI> fan LowestSpeed WarningSpeed
```

Example:

CLI>fan

Cooling Element (0x03):

=====

SPEED

NAME	CODE	RPM	STATUS
Fan 01	2	3690	OK
Fan 02	2	4090	OK
Fan 03	2	3650	OK
Fan 04	2	4050	OK

Current FAN Speed Attribute:

Lowest SpeedCode: 2

Warning SpeedCode: 5

CLI>fan 3 7

New FAN Speed Attribute:

Lowest SpeedCode: 3

Warning SpeedCode: 7

Current FAN Speed Attribute:

Lowest SpeedCode: 2

Warning SpeedCode: 5

CLI>st

CLI>

Reboot to take effect.

CLI>fan

Cooling Element (0x03):

=====

SPEED

NAME	CODE	RPM	STATUS
------	------	-----	--------

Fan 01	3	4140	OK
Fan 02	3	4630	OK
Fan 03	3	4140	OK
Fan 04	3	4490	OK

Current FAN Speed Attribute:

Lowest SpeedCode: 3

Warning SpeedCode: 7

Fan internal command for different fan speed type:

fan -t [high | normal | low | vlow]

high : 6000 - 10000 rpm

normal : 1800 - 7000 rpm

low : 1000 - 2000 rpm

vlow : below 1000 rpm

The above is a rough value, user can set different to fit the fan speed type.

Default is normal.

SPIN Command

The spin command defines the mode of staggering SATA drive spin-up function connected on the expander box. This command gives expander box the ability to spin up the disk drives sequentially or in groups, allowing the drives to come ready at the optimum time without straining the system power supply.

Staggering drive spin-up in a multiple drive environment also avoids the extra cost of a power supply designed to meet short-term startup power demand as well as:

Syntax

```
CLI> spin [ Delay(D)[ms] Num(D) ]
```

Expander issues the spin up the drives by [Num] drives with [Delay] ms.

Example1:

```
CLI>spin
```

Current SpinUp Attribute:

Drive Number: 1

Delay: 1024 ms

CLI>spin 512 3

New SpinUp Attribute:

Drive Number: 3

Delay: 512 ms

Current SpinUp Attribute:

Drive Number: 1

Delay: 1024 ms

ST Command

The st command stores system configurations in flash. Since all the revised parameter setting is temporarily stored in the working RAM, the ST command saves those parameters permanently in flash ROM.

1. Store temporarily configurations in flash

Syntax

CLI> st

Example:

CLI> st

CLI>

2. Store factory default configurations in flash

Syntax

CLI>st [default]

Example:

CLI>st default ;; restore the setting to default

CLI>

LSD Command

The lsd command is use for show the element devices status in the expander controller. With parameter, this command only show the select device status.

Syntax

CLI> lsd [hdd | temp | volt | pwr | con | ..]

Show SES elements information:

ArrayDevice Element (0x17):

=====

NAME	PHY	NLR		MAX	MIN	TYPE	ADDRESS
SLOT 01		0	3.0G	10	9	SAS	5000C500-0D2002D1
SLOT 02		1			10	9	
SLOT 03		2			10	9	
SLOT 04		3	1.5G	10	9	SATA	5001B469-84965C03
SLOT 05		4			10	9	
SLOT 06		5			10	9	
SLOT 07		6	6.0G	10	9	SAS	5000C500-17C8FD25
SLOT 08		7			10	9	
SLOT 09		8			10	9	
SLOT 10		9			10	9	
SLOT 11		10			10	9	
SLOT 12		11			10	9	

Connector Element (0x19):

=====

NAME	PHY	NLR	TYPE	STATUS
Connector00	16		02	
Connector00	17		02	
Connector00	18		02	
Connector00	19		02	
Connector01	20	6.0G	02	Connected
Connector01	21	6.0G	02	Connected
Connector01	22	6.0G	02	Connected
Connector01	23	6.0G	02	Connected
Connector02	24		02	
Connector02	25		02	
Connector02	26		02	
Connector02	27		02	

Cooling Element (0x03):

=====

SPEED

NAME	CODE	RPM	STATUS
Fan 01	5	2100	OK
Fan 02	5	2200	OK
Fan 03			Not-Installed
Fan 04			Not-Installed

Temperature Element (0x04):

=====

NAME	ID	CT('C)	HTW	LTW	OTWarn	
ENC. Temp	01	32		60	5	No
Chip Temp	02	42		85	0	No

Voltage Element (0x12):

```
=====
```

NAME	VOLT(V)	OVLMT	UVLMT	STATUS
1V	0.99	1.07	0.94	None
5V	4.96	5.32	4.63	None

PowerSupply Element (0x02):

```
=====
```

NAME	STATUS
PowerSupply01	OK
PowerSupply02	OK

AudibleAlarm Element (0x06):

```
=====
```

NAME	STATUS	ALMSTATE
Audible-Alarm	Normal	0

CLI>

SHOWLOGS Command

The showlogs command allows you to display system event notifications that have been generated event by the SAS expander box.

Syntax

CLI>showlogs [DisplayMode(hex, detail, default)]

Example:

CLI>showlogs

00000000-00000000:PLATFORM:Firmware initialization started

Day00000-00:00:00 ENCLOSURE-Fan 01 Failed

FDL Command

The SAS JBOD has added the expander firmware update through the CLI on the external RS-232 port. Before you process the firmware update, there are two block regions that you can update expander microcode on SAS JBOD.

1. CODE region - for FW file : sas3xfwYYMMDD.fw
2. MFGB region - for Data file : mfg12gYYMMDD.rom

To update the expander controller firmware, follow the procedure below:

Syntax: all the commands please type in lower case

```
CLI>fdl { code | mfgb }
```

Then use XModem/(Checksum) protocol transmit file to update ROM Region. The following procedures is used to update firmware through the RS-232:

1. Open any UART communication tools like HypeTerminal (115200,n,8,1).
2. Press any key on HyperTerminal window, the window will show "CLI>" prompt.

3. Type help will show help screen.

4. One command to update firmware. Step as follow.

5. Issue download & update command under "CLI>".

```
CLI>fdl code
```

Please Use XModem Protocol for File Transmission.

Use Q or q to quit Download before starting XModem.

<----expander prompt for ready to receive file to update.

6. Then under HyperTerminal program, use the pull down menu item transfer "Send" -> send files when dialog box prompt, choose "Xmodem" and the file in the directory then press "send".

- (a). If the expander receive the file under the timeout limit (60s), the process starts.

- (b). If time out, please retry the step E again.

7. You can also cancel the program step by type 'q'.
8. If transfer OK, the transferred data is updated. Cold-start expander (Power cycle again) to take effect.

Example:

Update procedure, use Xmodem to transfer, refer to "fdl" command for detail operation.

```
CLI> fdl { code | mfgb }
```

Use HyperTerminal or TeraTerm utility with Xmodem mode to transfer and update files.

If transfer OK, the transferred data is updated. Cold-start expander (Power cycle again) to take effect.

The following firmware and data are available in the following filename format.

1. FW file (CODE) : sas3xfwYYMMDD.fw
2. Data file (MFGB) : mfg12gYYMMDD.rom

Update SAS expander firmware:

```
CLI> fdl code
```

Use HyperTerminal or TeraTerm utility with Xmodem mode to transfer sas3xfwYYMMDD.fw.

If transfer OK, the transfer data is updated. Cold-start expander (Power cycle again) to take effect.

Update SAS expander data file:

```
CLI>fdl mfgb
```

Use HyperTerminal or TeraTerm utility with Xmodem mode to transfer mfg12gYYMMDD.rom.

If transfer OK, the transfer data is updated. Cold-start expander (Power cycle again) to take effect.

Counters Reset Command

Display/Reset all phy counters counters reset (optional).

```
CLI>counters reset
```

Phy counters successfully reset.

```
CLI>counters
```

```
Phy Layer Error Counters=====
```

```
== InvWrdCnt ==DispErrCnt ==LossSyncCnt ==RstSeqFailCnt=
```

```
Phy 00 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 01 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 02 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 03 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 04 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 05 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 06 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 07 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 08 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 09 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 10 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 11 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 12 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 13 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 14 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 15 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 16 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 17 0x00000000 0x00000000 0x00000000 0x00000000
```

```
Phy 18 0x00000000 0x00000000 0x00000000 0x00000000
```

Phy 19 0x00000000 0x00000000 0x00000000 0x00000000

Phy 20 0x00000000 0x00000000 0x00000000 0x00000000

Phy 21 0x00000000 0x00000000 0x00000000 0x00000000

Phy 22 0x00000000 0x00000000 0x00000000 0x00000000

Phy 23 0x00000000 0x00000000 0x00000000 0x00000000

Phy 24 0x00000000 0x00000000 0x00000000 0x00000000

Phy 25 0x00000000 0x00000000 0x00000000 0x00000000

Phy 26 0x00000000 0x00000000 0x00000000 0x00000000

Phy 27 0x00000000 0x00000000 0x00000000 0x00000000

Link Layer Event Counters

Phy Event Counter Not Configured.

Generic Broadcast Counter

Broadcast Counter Not Configured.

Generic Broadcast Counter

Broadcast Counter Not Configured.

Sasaddr Command

CLI>sasaddr

Expander New SAS Address: 0x5001B4690400083F

Expander Current SAS Address:

EXP Port SAS Address: 0x5001B4690400083F

SXP Port SAS Address: 0x5001B4690400083D

STP Port SAS Address: Disabled

Appendix D.

LCD Configuration Manager

The AccuSTOR LCD configuration utility is a character-based utility that you can run after powering the unit. Use LCD configuration utility to see and configure:

- Alerts Menu,
- Voltage,
- Set Link,
- Set Alarm,
- Set Password,
- Save Config, and
- System Reset


The LCD display front panel function keys are the primary user interface. Except for the "Firmware update", all configurations can also be performed through this interface.

Navigation Map of the LCD

The password option allows user to set or clear the password protection feature. Once the password has been set, the user can only monitor and configure the unit by providing the correct password. The password is used to protect the unit from unauthorized entry.

The unit will check the password only when entering the main menu from the initial screen. The unit will automatically go back to the initial screen when it does not receive any command in 5 minutes. The unit's password is default setting at 0000 by the manufacture.

The following flow is an expansion of LCM setup option items hierarchical menu.
LCM setup option items hierarchical menu:



- **Alerts Menu**

Show which device that fail to work, its sub-items could be "Power Supply", "Fan", "Temp. Sensor" and "Voltage Sensor".

- **Voltage**

Show enclosure chip voltage in status data, represent in V.

The sub-items are shown as below:

1.2V- , the expander box voltage is 1.2V

5V- , the expander box voltage is 5V

For the setup item, the LCM key represent:

Up key to enter the 0 - 9 data.

Down key to enter "a" - "z" and "A" - "Z" data.

Enter key to confirm the input or ready to update a sub-item data.

Esc/Exit key to go back to the main selection.

- **Set Link**

Set HDD devices maximum /minimum link speed rate. The value could be 12G, 6G or 3G each of HDD devices link speed will have the sub-items are shown as below:

_Set Max. Rate

12G

_Set Min. Rate

3G

- **Set Alarm**

Set enclosure buzzer warning/critical error beep style or mute the current beep. The value could be "Sound 1", "Sound 2", "Sound 3", "Sound 4" and "Sound Disabled". Sound 1 to 4 means different frequency sound. Sound disabled means disable the sound beep. The sub-items are shown below:

_Set Alarm Beep

Mute beep

_Warning Alarm

Sound 2

_Critical Alarm

Sound 3

- **Set Password**

Change the enclosure LCM/UART CLI password. The sub-item is "Set New PWD".

- **Save Config**

Save all the updated option value into non-volatile memory area.

- **System Reset**

Reboot the system.

Appendix E. Specifications

Specifications

Model	AS424X12(R)	AS316X12(R)	AS212X12(R)
System Type	4U Rackmount		
Expander numbers	1 or 2	1 or 2	1 or 2
Host Interface	Single minSAS HD (SFF-8644) connectors (4 x 12Gb Links) / Expander		
Host Transfer Rate	12Gb/ Sec		
Disk Interface	SAS 3.0, 12Gbps/ Port 2 x minSAS HD (SFF-8644) for Expansion		
Disk Channel	24 x SAS 3.0, 12Gb	16x SAS 3.0, 12Gb	12 x SAS 3.0, 12Gb
Hot Swap and redundant	Yes (Expander box, Power Supply, Drive and Fan).		
Hot Spare	Yes (Drive).		
Monitoring / Indicators	Through In-band SES (SCSI Enclosure Service) LED Indicators on Front Panel		
Remote Terminal Configuration	Yes.		
Operating Systems	O/S Independent and Transparent		
Power Supply	500+500+500 watts Redundancy 80 Plus energy-Efficient power system, Three 500 watts module with PFC function. Load sharing type and cable-less design with Redundancy Three Power inlet	500+500 watts Redundancy 80 Plus energy-Efficient power system, two 500 watts module with PFC function. Load sharing type and cable-less design with Redundancy Dual Power inlet	
Electrical	AC Voltage 100-240 VAC Ac Frequency 47-63Hz		
Temperature	Operating Temperature : 5 to 35 degree C. Non Operating Temperature : -40 to 60 degree C.		
Relative Humidity	20% to 80% non-condensing		
Dimensions	446.5mm(W)*517mm(D)*4U	446.5mm(W)*517mm(D)*3U	446.5mm(W)*527mm(D)*2U

Model	AS224X12(R)
System Type	2U Rackmount
Expander numbers	1 or 2
Host Interface	Single minSAS HD (SFF-8644) connectors (4 x 12Gb Links) / Expander
Host Transfer Rate	12Gb/ Sec
Disk Interface	SAS 3.0, 12Gbps/ Port 2 x minSAS HD (SFF-8644) for Expansion
Disk Channel	24 x SAS 3.0, 12Gb
Hot Swap and redundant	Yes (Expander box, Power Supply, Drive and Fan).
Hot Spare	Yes (Drive).
Monitoring / Indicators	Through In-band SES (SCSI Enclosure Service) LED Indicators on Front Panel
Remote Terminal Configuration	Yes.
Operating Systems	O/S Independent and Transparent

Power Supply	500+500 watts Redundancy 80 Plus energy-Efficient power system, two 500 watts module with PFC function. Load sharing type and cable-less design with Redundancy Dual Power inlet
Electrical	AC Voltage 100-240 VAC Ac Frequency 47-63Hz
Temperature	Operating Temperature : 5 to 35 degree C. Non Operating Temperature : -40 to 60 degree C.
Relative Humidity	20% to 80% non-condensing
Dimensions	449mm(W)*468mm(D)*2U



Specifications subject to change without notice.
